BrightLink® Mounting Templates

For accurate placement, you must print these sheets at full size; do not reduce or enlarge.


Select a mounting template option below

Full Size Single Sheet Template

Requires a wide-carriage printer.

Segmented Template

For printing on 3-letter-sized pages





Template sheet
Fiche modèle
Plantilla
Folha modelo
Schablone
Dima
模板片
模板片
テンプレートシート
CPD-28018
1.77 inches
45 mm
1.77 inches
45 mm
For accurate placement, make sure you print this sheet at full size. Do not reduce or enlarge (requires a wide-carriage printer).
A
C
A
B
C
B
CTR
B
A
C
A
B

For accurate placement, make sure you print these sheets at full size; do not reduce or enlarge. If you are using Adobe® Reader®, make sure **Page Scaling** is set to **None** and **Auto-Rotate and Center** is selected.

Trim the left and right sides of the sheets as needed, then carefully align the sheets before taping them together.

CPD-28209




1.77 inches
45 mm
C
C
CTR
C

Pour un placement précis, assurez-vous d'imprimer ces feuilles dans le format pleine page; ne réduisez pas ou n'agrandissez pas la taille. Si vous utilisez Adobe Reader, assurez-vous que le réglage de **Mise à l'échelle** est réglé à **Aucune** et que **Rotation auto. et centrage des pages** est sélectionné.

Au besoin, coupez les côtés gauche et droit des feuilles et ensuite, alignez les feuilles avant de les joindre à l'aide de ruban adhésif.

